




TO RE-ASSEMBLE THE AB HUB

Proceed as follows:

1. If the left-hand ball cup has been removed from the hub shell, use the special tool (box spanner DD911) to replace it, and remember that it must be screwed anti-clockwise because it has a *left-hand thread*. The joint between the ball cup and the hub shell must be cemented with a good sealing compound to prevent oil from leaking through to the brake shoes. Either the slight recess in the shell or the face of the shoulder on the ball cup which makes contact with the shell should be well painted over with sealing compound before the ball cup is screwed home.
2. Prepare the following preliminary sub-assemblies:
 - a. Fit the ball cage into the driver, with the ring of the ball-retainer facing outwards and the recess in the dust cap also facing outwards. If a new ball-retainer is being fitted, the dust

cap also should be new. If the sprocket has been removed, see No. 19 below.

- b. Fit the balls (only 24) and the inner dust cap to the right-hand ball ring, making sure that the balls can revolve freely with the dust cap in place.
 - c. Fit the pawls, pins and springs into the gear ring as described in the general instructions to 'The Re-assembling of Sturmev-Archer Hubs.' (The planet-cage pawls, pins and springs are not fitted at this stage.)
 - d. Smear grease in the channels of the dust caps of the driver and in the recess of the right-hand ball ring. *Do not use grease anywhere else.*
3. Hold the left-hand end of the axle in a vice, so that the slot for the axle key is above the sun pinion, and fit the planet cage.
 4. Add the planet pinions and pins. (The small ends of the pins protrude.)

5. Fit the sleeve (flange first), the sliding clutch with the recess over the flange of the sleeve, and the axle key (with the flat of the key facing upwards), and screw in the indicator rod to hold them in that position.
6. Fit the thrust ring and washer, making sure that the flatted ends of the key engage properly in the slots of the thrust ring.
7. Fit the previously prepared gear-ring sub-assembly.
8. Fit the previously prepared right-hand ball-ring sub-assembly.
9. Fit the previously prepared driver sub-assembly.
10. Drop the clutch spring over the axle.
11. Fit the cap and screw up the right-hand cone *finger-tight*. Then slacken it back half a turn and lock it in that position with the special washer and locknut. On no account must the cone be unscrewed more than half a turn, as that would throw the gear mechanism out of adjustment.
12. Invert the assembly in the vice and fit the planet-cage pawls as described in the general instructions to 'The Re-assembling of Sturmey-Archer Hubs.'
13. Remove the assembled mechanism from the vice and, while holding it with the planet cage uppermost, pour about two teaspoonfuls of a good quality thin oil into the cage.
14. Hold the cycle wheel in the left hand, with the open (right-hand) end of the hub shell facing downwards, and insert the assembled mechanism from below, screwing up the right-hand ball ring finger-tight only.
15. Make sure that the position marks made on the ball ring and the hub flange before dismantling will register properly, and then screw up tightly.
16. Fit the left-hand cone and spacing washer.
17. Replace the brake anchor plate complete with shoes. (If the shoes have been removed, make sure when replacing them that the longer of the two short arms on the cam spindle is pointing towards the drum surface and the shorter one towards the hub axle; otherwise only one shoe will be brought into action when the brake is operated.) If the brake shoe assembly has been dismantled, see general instructions.
18. Fit the outer washers, the notched cone-adjusting washer, and the left-hand locknut in the arrangement noted when dismantling the hub. Adjust the hub bearing as described in 'The Fitting Adjustment of Sturmey-Archer Hubs.'
19. If the sprocket has been removed from the driver, fit the outer dust cap over the driver before replacing the sprocket, and see that the dust cap is properly centred on the flange of the driver. Replace the sprocket and spacing washers in the arrangement noted when dismantling, and add the circlip.
20. Replace the wheel in the cycle frame and adjust the gear as described in 'The Fitting and Adjustment of Sturmey-Archer Hubs.'

